



# SET-UP GUIDE








## Unpack

- 48" ~ 55"  
M4 X L14 (4EA)  
M4 X L12 (4EA)
- 65"  
M4 X L14 (8EA)
- 4EA
- Regulatory Guide
- 3D Active Glasses


## Assemble




BN68-07054V-00



## Connect



When you connect or disconnect the One Connect Mini cable, the TV reboots with a reboot warning message.



## Initial Setup

